


## Air & Hydraulic Brakes



www.herbstmachinery.com

HERBST GENUINE SPARE PARTS

Description Air Tank 38.5 ltrs	Part No. HB0001
<b>Description</b> Relay Valve	Part No. HB0002
Description Air/Oil Pot c/w Small Clevis	Part No. HB0046




DescriptionPart No.Small ClevisHB0046A





B		
	Description	Part No.
are successive	Large Clevis	HB0047A



Description	Part No.
Air/Oil Pot Adjuster	HB0048
Air/Oil Pot Return Spring	HB0049



Description	Part No.
1/2" Male Coupling A0100	HB0008
1/2" Female Coupling A0110	HB0007
Operating Sleeve 1/2" Valve Riser	HB0018



Description	Part No.
M22 Male Coupling A0105	HB0009
M22 Female Coupling A0115	HB0010



Description	Part No.
M22 Drain Valve	HB0016



## **Air Brakes**

 Description
 Part No.

 Relay Load Sensing Valve
 HB0051B



Description	Part No.
Load Sensing Valve	HB0051



Description	Part No.
Load Sensing Valve Spring	HB0052



Description	Part No.
Red Susie Line Coil 22 Turns	HB0006
Yellow Susie Line Coil 22 Turns	HB0005



Description	Part No.
M18x2 Black Air Line	HB0039
M12x2 Black Air Line	HB0040
M10x7.5 Black Air Line	HB0041

HERBST


www.herbstmachinery.com

Air Brakes		HERBST GENUINE SPARE PARTS
6	Description M22 Thrust Ring M22 O Ring	Part No. HB0022 HB0021
	Description M22 Bulkhead	Part No. HB0011
	Description M22-10 Bulkhead c/w Brass Insert	Part No. HB0017
	<b>Description</b> M22 x 1/2" Adapter	Part No. HB0012
ON A OFF	Description 1/2" BSP Shut Off Air Tap	Part No. HB0016T





-	Description	Part No.
California (		
The state of the s	M22 Male Plug	HB0015
	M16 Male Plug	HB0026
and the second second	Description	Part No.
	MI0 'T' c/w Test Point	HB0030
	The restront	
	Description	Part No.
	MI2 'T' c/w Test Point	HB0029
0		
	Description	Part No.
1-0-0	Description M16-10 Attach 'T'	
		Part No. HB0025
	MI6-10 Attach 'T'	HB0025
<image/>		
<image/>	MI6-10 Attach 'T'	HB0025





Air Brakes		HERBST GENUINE SPARE PARTS
	Description	Part No.
	MI6-10 Quick Attach ST	HB0023
	Description	Part No.
	M22 x 18 Quick Attach Straight	HB0013
	Description	Part No.
	M22 x 18 Quick Attach Elbow	HB0014




Hydraulic Brakes		HERBST GENUINE SPARE PARTS
	Description	Part No.
	Braking Ram Kit 25mm	HB0043
	Description	Part No.
	25mm Braking Ram Spring	HB0053
	Braking Ram Bracket	HB0053B
	Description 25mm Braking Ram	Part No. HB0053R
	Description	Part No.
	Braking Ram Kit 30mm	HB0044
G	Description	Part No.
	30mm Brake Ram Spring	HB0044A
	Braking Ram Clevis Pin	HB0045

www.herbstmachinery.com



Hydraulic Brakes	HERBST G	ENUINE SPARE PARTS
	Description	Part No.
	Break Away Coupling	
	Description	Part No.
	1/2" Female Brake Coupling	HB0032
	Description	Part No.
	1/2" Male BSP Coupling	HB0033
A de la deservación de		
	Description	Part No.
	1/2" Female Parking Station for Male Probe	HB0034
	1/2" Female Parking Station for Brake Coupling	HB0034S
	Description Spiral Guard SGX 16	Part No. HB0038





Hydraulic Brakes	HERBS	T GENUINE SPARE PARTS
Constanting and a second second	~~	
	Description	Part No.
	M6 Brake Cable	HB0035
	Brake Cable 6mm Thread Clamp	HB0036
	Brake Cable Adjuster	HB0037
	•	
	Description	Part No.
	Red Handbrake	HB0004
1		
/		
	Description	Part No.
	<b>Description</b> Handbrake For Dropside	
	<b>Description</b> Handbrake For Dropside	Part No. HB0003



Hydraulic Brakes		HERBST GENUINE SPARE PARTS
	<b>Description</b> Euro Fail Safe	Part No. HB0059
	Description Oil Accumulator	Part No. HB0060
	Description Trailer Wiring Harness	Part No. HB0061
	Description Tractor Wiring Harness	Part No. HB0062
	Description Electric Control Box	Part No. HB0063



